

ATM
User-Network
Interface
Specification

Version 3.1

ATM User-Network Interface Specification
Version 3.1
September, 1994

(C) 1994 The ATM Forum. All Rights Reserved. No part of this publication may be reproduced in any form or by any means.

The information in this publication is believed to be accurate as of its publication date. Such information is subject to change without notice and the ATM Forum is not responsible for any errors. The ATM Forum does not assume any responsibility to update or correct any information in this publication. Notwithstanding anything to the contrary, neither The ATM Forum nor the publisher make any representation or warranty, expressed or implied, concerning the completeness, accuracy, or applicability of any information contained in this publication. No liability of any kind shall be assumed by The ATM Forum or the publisher as a result of reliance upon any information contained in this publication.

The receipt or any use of this document or its contents does not in any way create by implication or otherwise:

- Any express or implied license or right to or under any ATM Forum member company's patent, copyright, trademark or trade secret rights which are or may be associated with the ideas, techniques, concepts or expressions contained herein; nor
- Any warranty or representation that any ATM Forum member companies will announce any product(s) and/or service(s) related thereto, or if such announcements are made, that such announced product(s) and/or service(s) embody any or all of the ideas, technologies, or concepts contained herein; nor
- Any form of relationship between any ATM Forum member companies and the recipient or user of this document.

Implementation or use of specific ATM recommendations and/or specifications or recommendations of the ATM Forum or any committee of the ATM Forum will be voluntary, and no company shall agree or be obliged to implement them by virtue of participation in the ATM Forum.

The ATM Forum is a non-profit international organization accelerating industry cooperation on ATM technology. The ATM Forum does not, expressly or otherwise, endorse or promote any specific products or services.

Acknowledgements

A specification of the breadth and significance as is contained in this document is possible only through the efforts of many individuals. The assistance of the numerous members of The ATM Forum who have brought contributions towards, discussed and reviewed the enclosed information is appreciated. It must not be overlooked that the Technical Committee was able to complete this implementation agreement because of the solid base of work performed by regional and international standards groups.

Special thanks are due to the "enablers" - the UNI 3.1 editing team led by Greg Ratta (Gregan Crawford, Bob Fenaglio, Henry Fowler, John Sikora and Rick Townsend) and the UNI 3.0 editing team led by Jim Grace (Richard Breault, Rao Cherukuri, John Jaeger, Jeff Kiel, Kieth McCloghrie and Lou Wajnaroski).

George Dobrowski
Chairman
The ATM Forum Technical Committee

Preface

Since the publication of the ATM User-Network Interface Specification, Version 3.0 (UNI 3.0), a number of international standards have been completed. In particular, recent progress within the ITU for the following ITU-T Recommendations: I.610, Q.2100, Q.2110, Q.2130 and Q.2931 has bearing on the interface specified in UNI 3.0. This version, UNI 3.1, of the interface specification has been created to bring The ATM Forum implementation agreements in line with the recent agreements in international standards and is intended to allow interoperation of equipment designed to the ATM Forum implementation agreements and equipment designed to international standards.

It should be noted that these changes render this new version incompatible with version 3.0 for signaling and signaling virtual channels.

Foreword

Asynchronous Transfer Mode (ATM) is widely acknowledged as the base technology for the next generation of global communications. ATM provides a unique ability to handle the real-time networking requirements of emerging multimedia applications, while providing compatibility with the increasing bandwidth needs for current installations. ATM solutions are being deployed throughout the wide area and enterprise network backbone, and all the way to the desktop and home. This User-Network Interface (UNI) document that you are reading defines the primary specification for end-system connection to ATM networks.

Progress toward the definition of global Asynchronous Transfer Mode (ATM) standards continues at a rapid pace. This is the second published edition of the ATM Forum UNI specification, and contains several new sections which further define the operation of ATM in Local and Wide Area Networks. It represents the next step in the process which will allow a uniform deployment of interoperable ATM technology.

The UNI specification is the result of the combined work of hundreds of companies from all sectors of the industry cooperating towards a common goal. The process which results in rapid convergence and final agreement of so many diverse interests on a single specification is both immense and mind-boggling. It is the strength and flexibility of the underlying ATM technology and its ability to best handle the many conflicting requirements that enables this continuing progress.

The Technical Committee of the ATM Forum creates the UNI specification. The committee meets every 2 months in different locations around the world for up to a week at a time. Typically over 500 people attend these meetings, representing a wide diversity of interests and knowledge. Technical contributions for the meeting, several hundred in number, are sent out electronically ahead of time to the entire membership. This allows participants to review the information before the actual meeting. Contributions are assigned to specific working groups of experts. After a period of discussion and voting, a single recommend document is forwarded to the ATM Forum membership for final review and approval.

From its initial formation in November of 1991, The ATM Forum has grown to over 600 member organizations at the time of this writing. A great deal of credit goes to the Technical Committee for its ability to maintain rapid progress in spite of the difficult logistics required to reach consensus between such a large number of participants.

The industry specifications from the ATM Forum are based on work of international standards organizations. Completion of this document is due to the active participation and dedication of member companies, and individuals who often give up much of their personal time to accomplish the work. I would particularly like to acknowledge the effort of George Dobrowski and Jim Grace, the Chair and Vice Chair of the ATM Forum Technical Committee for their leadership in guiding our diverse and ever-growing committee to final agreement.

Fred Sammartino
President and Chairman of the Board
The ATM Forum

Table of Contents

Section 1: Introduction	1
1.1 Purpose of Document	3
1.2 Scope of Document	4
1.3 Structure of Document	4
1.4 Terminology	5
1.5 ATM Bearer Service Overview	5
1.6 User-Network Interface Configuration	8
1.7 User-Network Interface Protocol Architecture	9
Section 2: Physical Layer Interfaces Specification	11
2.1 SONET STS-3c Physical Layer Interface	12
2.1.1 Physical Layer U-plane Specification	13
2.1.1.1 Physical Media Dependent (PMD) Specification	13
2.1.1.1.1 Physical Medium Characteristics at 155.52 Mbps	13
2.1.1.2 Transmission Convergence (TC) Sublayer Specification	14
2.1.1.2.1 B-ISDN Independent TC Sublayer Functions	14
2.1.1.2.2 B-ISDN Specific TC Sublayer Functions	14
2.1.1.2.2.1 HEC Generation/Verification	14
2.1.1.2.2.2 Cell Scrambling and Descrambling	15
2.1.1.2.2.3 Cell Mapping	15
2.1.1.2.2.4 Cell Delineation	15
2.1.1.2.2.5 ATM Payload Construction Indication	16
2.1.1.3 SONET STS-3c Frame at the UNI	16
2.1.2 Physical Layer Operation and Maintenance Specification (M-plane)	19
2.1.2.1 B-ISDN Independent Operation and Maintenance Functions	21
2.1.2.1.1 Performance Monitoring	21
2.1.2.1.2 Fault Management	22
2.1.2.1.3 Facility testing	22
2.1.2.2 B-ISDN Specific Operation and Maintenance Functions	22
2.1.2.2.1 Loss of Cell Delineation	22
2.2 DS3 Physical Layer Interface	23
2.2.1 Format at 44.736 Mbps	23
2.2.1.1 PLCP Format	25
2.2.1.2 PLCP Overhead Utilization	25
2.2.1.2.1 Framing Octets (A1, A2)	25
2.2.1.2.2 Bit Interleaved Parity - 8 (B1)	25
2.2.1.2.3 Cycle/Stuff Counter (C1)	26
2.2.1.2.4 PLCP Path Status (G1)	26
2.2.1.2.5 Path Overhead Identifier (P0-P11)	27
2.2.1.2.6 Growth Octets (Z1-Z6)	27
2.2.1.2.7 Trailer Nibbles	27
2.2.2 ATM Transfer Capability	28

2.2.3	Timing	28
2.2.4	Cell Payload Scrambling	28
2.2.5	Cell Delineation	28
2.2.6	HEC Generation/Verification	28
2.3	Physical Layer for 100 Mbps Multimode Fiber Interface	29
2.3.1	Physical Media Dependent (PMD) Specification	30
2.3.1.1	Physical Medium Characteristics	30
2.3.1.2	Line Coding	31
2.3.1.3	Line Rates and Bit Timing	32
2.3.2	Transmission Convergence (TC) Sublayer Specification	32
2.3.2.1	Idle Line	32
2.3.2.2	Cell Delineation	32
2.3.2.3	HEC Generation/Verification	33
2.4	Physical Layer for 155 Mbps Interface	34
2.4.1	Fiber Physical Medium Dependent Specification	34
2.4.1.1	Line Rates and Bit Timing	35
2.4.1.2	Fiber Optic Medium Characteristics	35
2.4.1.3	Optical Medium Connector Plug and Socket	36
2.4.1.4	Optical Characteristics	36
2.4.2	STP Physical Medium Dependent Specification	39
2.4.2.1	Line Rates and Bit Timing	40
2.4.2.2	Electrical Medium Characteristics	40
2.4.2.3	Electrical Medium Connector Plug and Socket	40
2.4.2.4	Electrical Characteristics	41
2.4.3	Transmission Convergence (TC) Specification	43
2.4.3.1	Line Coding	43
2.4.3.2	Transmission Frame Structure	43
2.4.3.3	Frame and Cell Delineation	44
2.4.3.4	125 μ sec Clock recovery	44
2.4.3.5	HEC Generation/Verification	45
2.4.4	Physical Layer Operation and Maintenance Specification (M-plane)	46
2.5	E3 Physical Layer Interface	47
2.6	E4 Physical Layer Interface	47
Section 3: ATM Layer Specification		49
3.1	ATM Layer Services	50
3.2	Service Expected from the Physical Layer	52
3.3	ATM Cell Structure and Encoding at the UNI	52
3.4	ATM Layer Functions Involved at the UNI (U-plane)	55
3.4.1	Multiplexing among different ATM connections	56
3.4.2	Cell rate decoupling	56
3.4.3	Cells discrimination based on pre-defined header field values	57
3.4.4	Cell discrimination based on Payload Type (PT) Identifier field values	59
3.4.5	Loss priority indication and selective cell discarding	60
3.4.6	Traffic Shaping	60

3.5	ATM Layer Management Specification (M-plane)	60
3.5.1	ATM Layer Management Information Flows	61
3.5.2	ATM OAM Cell Format	63
3.5.3	ATM Fault Management functions at the UNI	65
3.5.3.1	Alarm Surveillance	65
3.5.3.2	Connectivity Verification	66
3.5.3.2.1	End to End Loopback	67
3.5.3.2.2	UNI Loopback	67
3.6	Traffic Control and Congestion Control	68
3.6.1	Introduction	68
3.6.1.1	Objectives	69
3.6.1.2	Generic Functions	70
3.6.1.3	QoS, Network Performance and Cell Loss Priority	71
3.6.1.4	Relation with other Standard documents	71
3.6.2	User-Network Traffic Contract	72
3.6.2.1	Traffic Parameters and Descriptors	72
3.6.2.2	Traffic Contract Specification	74
3.6.2.3	Cell Conformance and Connection Compliance	75
3.6.2.4	Traffic Contract Parameter Specification	76
3.6.2.4.1	Generic Cell Rate Algorithm (GCRA)	77
3.6.2.4.2	Peak Cell Rate	79
3.6.2.4.2.1	Peak Cell Rate Reference Model	80
3.6.2.4.2.2	Peak Cell Rate Parameter Definition	81
3.6.2.4.2.3	Interpretation of the Definition of Peak Cell Rate and Equivalent Terminal	82
3.6.2.4.2.4	Cell Delay Variation Tolerance	82
3.6.2.4.3	Sustainable Cell Rate and Burst Tolerance	85
3.6.2.4.3.1	Sustainable Cell Rate and Burst Tolerance Reference Model	85
3.6.2.4.3.2	Sustainable Cell Rate and Burst Tolerance Parameter Definitions	85
3.6.2.4.3.3	Interpretation of the Definition of Sustainable Cell Rate and Burst Tolerance in Conjunction with Peak Cell Rate	86
3.6.2.4.3.4	Relationship of CDV Tolerance, SCR and Burst Tolerance	88
3.6.2.5	Conformance Definitions Supported at the Public UNI	89
3.6.2.5.1	Conformance Definition for PCR	89
3.6.2.5.2	Conformance Definition for PCR CLP=0+1 and SCR CLP=0	90
3.6.2.5.3	Conformance Definition for PCR CLP=0+1 and SCR CLP=0+1	90
3.6.3	Functions and Procedures for Traffic Control and Congestion Control at the UNI	91
3.6.3.1	Introduction	91

3.6.3.2 Traffic Control Functions	92
3.6.3.2.1 Network Resource Management	92
3.6.3.2.2 Connection Admission Control	95
3.6.3.2.3 Usage Parameter Control	96
3.6.3.2.3.1 UPC Functions	96
3.6.3.2.3.2 UPC Requirements	96
3.6.3.2.3.3 UPC location	98
3.6.3.2.3.4 Traffic parameters subject to control at the UPC	99
3.6.3.2.3.5 UPC actions	99
3.6.3.2.3.6 Relationship between UPC, CLP and Network Performance	100
3.6.3.2.3.7 Relationship Between UPC and OAM	101
3.6.3.2.4 Selective Cell Discard	101
3.6.3.2.5 Traffic Shaping (O)	101
3.6.3.2.6 Explicit Forward Congestion Indication	102
3.6.3.3 Congestion Control Functions	102
3.6.3.3.1 Selective Cell Discard	103
3.6.3.3.2 Reaction to UPC failures	103
Section 4: Interim Local Management Interface Specification	105
4.1 Interim Local Management Interface (ILMI) Functions	108
4.2 ILMI Service Interface	110
4.2.1 System (R)	111
4.2.2 Physical Layer (R)	112
4.2.3 ATM Layer (R)	112
4.2.4 ATM Layer Statistics (O)	112
4.2.5 Virtual Path Connections (R)	112
4.2.6 Virtual Channel Connections (R)	112
4.3 Simple Network Management Protocol (SNMP)	113
4.4 Management Information Base (MIB) Model for ILMI Managed Objects	113
4.4.1 Per-System UNI MIB Attributes (R)	113
4.4.2 Per-Physical Interface UNI MIB Attributes (R)	113
4.4.2.1 Common (R)	114
4.4.2.1.1 Interface Index (R)	114
4.4.2.1.2 Interface Address (O)	114
4.4.2.1.3 Transmission Type (R)	114
4.4.2.1.4 Media Type (R)	115
4.4.2.1.5 Physical Layer Operational Status (R)	115
4.4.2.1.6 Adjacency Information	115
4.4.2.2 Transmission Type Specific Information (R)	115
4.4.2.2.1 SONET STS-3c Physical Layer Interface	115
4.4.2.2.2 DS3 Physical Layer Interface	115
4.4.2.2.3 Physical Layer for 100 Mbps Interface	115
4.4.2.2.4 Physical Layer for 155 Mbps Interface	115

4.4.3	Per-ATM Layer Interface UNI MIB Attributes (R)	116
4.4.3.1	Interface Index (R)	116
4.4.3.2	Configuration Information (R)	116
4.4.3.2.1	Maximum Number of VPCs (R)	116
4.4.3.2.2	Maximum Number of VCCs (R)	116
4.4.3.2.3	Number of Configured VPCs (R)	117
4.4.3.2.4	Number of Configured VCCs (R)	117
4.4.3.2.5	Maximum Number of Active VPI bits (R)	117
4.4.3.2.6	Maximum Number of Active VCI bits (R)	117
4.4.3.2.7	ATM UNI Port Type (R)	117
4.4.3.2.8	ATM UNI Version (R)	117
4.4.4	ATM Layer Statistics (O)	117
4.4.4.1	ATM Cells Received (O)	118
4.4.4.2	ATM Cells Dropped on the Receive Side (O)	118
4.4.4.3	ATM Cells Transmitted (O)	118
4.4.5	Per-Virtual Path UNI MIB Attributes (R)	118
4.4.5.1	Interface Index (R)	119
4.4.5.2	VPI (R)	119
4.4.5.3	Transmit Traffic Descriptor (R)	119
4.4.5.4	Receive Traffic Descriptor (R)	119
4.4.5.5	Operational Status (R)	119
4.4.5.6	Transmit (QoS) Class (R)	119
4.4.5.6	Receive (QoS) Class (R)	119
4.4.6	Per-Virtual Channel UNI MIB Attributes (R)	120
4.4.6.1	Interface Index (R)	120
4.4.6.2	VPI (R)	120
4.4.6.3	VCI (R)	120
4.4.6.4	Transmit Traffic Descriptor (R)	120
4.4.6.5	Receive Traffic Descriptor (R)	120
4.4.6.6	Operational Status (R)	120
4.4.6.7	Transmit (QoS) Class (R)	121
4.4.6.8	Receive (QoS) Class (R)	121
4.4.7	ILMI Traps (R)	121
4.5	Relationship to Other MIBs	121
4.5.1	Relationship to the 'system' group (R)	121
4.6	Actual MIB	122
4.6.1	Objects	122
4.6.1.1	Textual Conventions	123
4.6.1.2	Use of Counters	123
4.6.1.3	Meaning of Transmit/Receive	123
4.6.2	Definitions	123
4.7	ILMI Protocol	147
4.7.1	Use of VCCs	147
4.7.2	Message Format (R)	147
4.7.3	Message Sizes (R)	148

4.7.4	ILMI Traffic Requirements	148
4.7.5	Message Response Time	148
4.7.6	Object Value Data Currentness	149
4.7.7	Link Management Procedures	149
Section 5: UNI Signalling		151
5.1	General	151
5.1.1	Scope	151
5.1.1.1	Reference Configuration	151
5.1.2	Capabilities Supported by Phase 1 Signalling	153
5.1.2.1	Support of Demand (Switched) Channel Connections	154
5.1.2.2	Support of Point-to-Point and Point-to-Multipoint Channel Connections	154
5.1.2.2.1	Definition of Point-to-Multipoint Connection	154
5.1.2.2.2	Support of Point-to-Multipoint Channel Connections	155
5.1.2.3	Support of Connections with Symmetric or Asymmetric Bandwidth	155
5.1.2.4	Support of a Single Connection per Call	156
5.1.2.5	Protocol Support for Basic Signalling Functions	156
5.1.2.6	Support of Class X, Class A, and Class C ATM Transport Services ...	157
5.1.2.7	Support of Signalling Parameter "Request and Indication"	157
5.1.2.8	VPI/VPCI/VCI Support	157
5.1.2.9	Support of a Single Signalling Virtual Channel	158
5.1.2.10	Support of Error Recovery	158
5.1.2.11	Support of Public UNI and Private UNI ATM Addressing	158
5.1.2.12	Support of a Client Registration Mechanism	158
5.1.2.13	Support of End-to-end Compatibility Parameter Identification	159
5.1.2.14	Support of Multicast Service Addresses	159
5.1.3	Addressing	159
5.1.3.1	Private Networks	159
5.1.3.1.1	Authority and Format Identifier (AFI)	161
5.1.3.1.1.1	Data Country Code (DCC)	161
5.1.3.1.1.2	International Code Designator (ICD)	162
5.1.3.1.1.3	E.164 (E.164)	162
5.1.3.1.2	Domain Specific Part (DSP)	162
5.1.3.1.2.1	HO-DSP	162
5.1.3.1.2.2	End System Identifier (ESI)	162
5.1.3.1.2.2	Selector	162
5.1.3.2	Public Networks	163
5.2	Overview of Call Control	163
5.2.1	ATM Call States	163
5.2.1.1	Call States at the User Side of the Interface	164
5.2.1.1.1	Null (U0)	164
5.2.1.1.2	Call Initiated (U1)	164
5.2.1.1.3	Outgoing Call Proceeding (U3)	164

5.2.1.1.4	Call Delivered (U4)	164
5.2.1.1.5	Call Present (U6)	164
5.2.1.1.6	Call Received (U7)	164
5.2.1.1.7	Connect Request (U8)	164
5.2.1.1.8	Incoming Call Proceeding (U9)	164
5.2.1.1.9	Active (U10)	164
5.2.1.1.10	Release Request (U11)	165
5.2.1.1.11	Release Indication (U12)	165
5.2.1.2	Call States at the Network Side of the Interface	165
5.2.1.2.1	Null (N0)	165
5.2.1.2.2	Call Initiated (N1)	165
5.2.1.2.3	Outgoing Call Proceeding (N3)	165
5.2.1.2.4	Call Delivered (N4)	165
5.2.1.2.5	Call Present (N6)	165
5.2.1.2.6	Call Received (N7)	165
5.2.1.2.7	Connect Request (N8)	165
5.2.1.2.8	Incoming Call Proceeding (N9)	165
5.2.1.2.9	Active (N10)	166
5.2.1.2.10	Release Request (N11)	166
5.2.1.2.11	Release Indication (N12)	166
5.2.1.2.12	Call Abort (N22)	166
5.2.2	ATM Call States Relating to Interworking Requirements	166
5.2.3	States Associated with the Global Call Reference	166
5.2.3.1	Call States at the User Side of the Interface	166
5.2.3.1.1	Null (Rest 0)	166
5.2.3.1.2	Restart Request (Rest 1)	166
5.2.3.1.3	Restart (Rest 2)	166
5.2.3.2	Call States at the Network Side of the Interface	167
5.2.3.2.1	Null (Rest 0)	167
5.2.3.2.2	Restart Request (Rest 1)	167
5.2.3.2.3	Restart (Rest 2)	167
5.3	Message Functional Definitions and Contents	167
5.3.1	Messages for ATM point-to-point call and connection control	168
5.3.1.1	ALERTING	168
5.3.1.2	CALL PROCEEDING	169
5.3.1.3	CONNECT	170
5.3.1.4	CONNECT ACKNOWLEDGE	171
5.3.1.5	RELEASE	171
5.3.1.6	RELEASE COMPLETE	172
5.3.1.7	SETUP	173
5.3.1.8	STATUS	175
5.3.1.9	STATUS ENQUIRY	176
5.3.2	Messages for the Support of 64 kbit/s based ISDN Circuit Mode Services	176
5.3.3	Messages Related to Release 1 Supplementary Services	176
5.3.4	Messages Used with the Global Call Reference	176

5.3.4.1	RESTART	177
5.3.4.2	RESTART ACKNOWLEDGE	178
5.3.5	Messages for Point-to-multipoint call and connection control	178
5.3.5.1	ADD PARTY	179
5.3.5.2	ADD PARTY ACKNOWLEDGE	181
5.3.5.3	ADD PARTY REJECT	181
5.3.5.4	DROP PARTY	182
5.3.5.5	DROP PARTY ACKNOWLEDGE	182
5.4	General Message Format and Information Element Coding	183
5.4.1	Overview	183
5.4.2	Protocol Discriminator	184
5.4.3	Call Reference	185
5.4.4	Message Type and Message Length	187
5.4.4.1	Message Type	187
5.4.4.2	Message Length	189
5.4.5	Variable Length Information Elements	189
5.4.5.1	Coding Rules	189
5.4.5.2	Extension of Codesets	195
5.4.5.3	Broadband Locking Shift Procedures	195
5.4.5.4	Broadband Non-Locking Shift Procedures	195
5.4.5.5	ATM Adaptation Layer Parameters	196
5.4.5.6	ATM Traffic Descriptor	203
5.4.5.7	Broadband Bearer Capability	209
5.4.5.8	Broadband High Layer Information	211
5.4.5.9	Broadband Low Layer Information	212
5.4.5.10	Call State	218
5.4.5.11	Called Party Number	219
5.4.5.12	Called Party Subaddress	220
5.4.5.13	Calling Party Number	222
5.4.5.14	Calling Party Subaddress	224
5.4.5.15	Cause	225
5.4.5.16	Connection Identifier	231
5.4.5.17	End-to-End Transit Delay	232
5.4.5.18	Quality of Service Parameter	233
5.4.5.19	Broadband Repeat Indicator	234
5.4.5.20	Restart Indicator	236
5.4.5.21	Broadband Sending Complete	237
5.4.5.22	Transit Network Selection	238
5.4.6	Information Elements for Interworking with 64 kbit/s Based ISDN	239
5.4.7	Information Elements for Supplementary Services	239
5.4.8	ATM Forum Specified Information Elements	239
5.4.8.1	Endpoint Reference	239
5.4.8.2	Endpoint State	240
5.5	Call/Connection Control Procedures For ATM Point-to-Point Calls	241
5.5.1	Call/Connection establishment at the originating interface	242

5.5.1.1	Call/Connection request	242
5.5.1.2	Connection Identifier (VPCI/VCI) Allocation/Selection	242
5.5.1.2.1	Connection Identifier Allocation/Selection - Origination	242
5.5.1.2.2	Use of VPCIs	243
5.5.1.2.3	VPCI and VCI Ranges	243
5.5.1.3	QoS and Traffic parameters selection procedures	243
5.5.1.4	Invalid Call/Connection control information	244
5.5.1.5	Call/Connection proceeding	244
5.5.1.6	Call/Connection confirmation indication	245
5.5.1.7	Call/Connection acceptance	245
5.5.1.8	Call/Connection rejection	245
5.5.1.9	Transit network selection	245
5.5.1.10	Extensions for symmetric call operation	245
5.5.2	Call/Connection establishment at the destination interface - Point-to-Point Access Configuration Call Offering	245
5.5.2.1	Incoming Call/Connection request	245
5.5.2.2	Address and Compatibility Check	246
5.5.2.3	Connection identifier (VPCI/VCI) allocation/selection — destination	246
5.5.2.4	QoS and Traffic parameter selection procedures	246
5.5.2.5	Call/Connection confirmation	247
5.5.2.5.1	Response to SETUP	247
5.5.2.5.1.1	Procedures when the User is an ATM endpoint	247
5.5.2.5.1.2	Procedures when the User is not an ATM endpoint	247
5.5.2.5.2	Receipt of CALL PROCEEDING	247
5.5.2.5.3	Called user clearing during incoming call establishment	247
5.5.2.5.4	Call failure	248
5.5.2.6	Call/Connection acceptance	248
5.5.2.7	Active indication	248
5.5.3	Call/Connection establishment at the destination — Point-to-multipoint access arrangement call offering	248
5.5.4	Call/Connection clearing	248
5.5.4.1	Terminology	249
5.5.4.2	Exception conditions	249
5.5.4.3	Clearing initiated by the user	249
5.5.4.4	Clearing initiated by the network	250
5.5.4.5	Clear collision	250
5.5.5	Restart procedure	250
5.5.5.1	Sending RESTART	251
5.5.5.2	Receipt of RESTART	252
5.5.6	Handling of error conditions	253
5.5.6.1	Protocol discrimination error	253
5.5.6.2	Message too short	253
5.5.6.3	Call reference error	253
5.5.6.3.1	Invalid call reference format	253

5.5.6.3.2	Call reference procedural errors	254
5.5.6.4	Message type or message sequence errors	254
5.5.6.5	Message length error	255
5.5.6.6	General information element errors	255
5.5.6.6.1	Information element sequence	255
5.5.6.6.2	Duplicated information elements	255
5.5.6.6.3	Coding standard error	255
5.5.6.7	Mandatory information element error	256
5.5.6.7.1	Mandatory information element missing	256
5.5.6.7.2	Mandatory information element content error	256
5.5.6.8	Non-mandatory information element errors	257
5.5.6.8.1	Unrecognized information element	257
5.5.6.8.2	Non-mandatory information element content error	258
5.5.6.8.3	Unexpected recognized information element	258
5.5.6.9	Signalling AAL reset	258
5.5.6.10	Signalling AAL failure	259
5.5.6.11	Status enquiry procedure	259
5.5.6.12	Receiving a STATUS message	260
5.5.7	Forward Compatibility Procedures	261
5.6	Call/Connection Control Procedures for Point-to-Multipoint Calls	261
5.6.1	Adding a party at the originating interface	263
5.6.1.1	Set up of the first party	263
5.6.1.2	Adding a Party	264
5.6.1.3	Invalid Call/Connection Control Information or Service Request in the ADD PARTY message	265
5.6.1.4	Add Party Received	266
5.6.1.5	Add Party Connected	266
5.6.1.6	Add Party Rejection	266
5.6.2	Add party establishment at the destination interface	266
5.6.2.1	Incoming add party request	266
5.6.2.2	Address and compatibility check	267
5.6.2.3	Connection identifier (VPCI/VCI) allocation/selection — destination	267
5.6.2.4	QoS and Traffic parameter selection procedures	268
5.6.2.5	Call/Connection confirmation	268
5.6.2.5.1	Response to ADD PARTY	268
5.6.2.5.1.1	Procedures when the user is an ATM endpoint	268
5.6.2.5.1.2	Procedures when the user is not an ATM endpoint	268
5.6.2.5.2	Called user rejection of incoming call establishment	269
5.6.2.5.3	Call failure	269
5.6.2.6	Call/Connection accept	269
5.6.2.7	Active indication	269
5.6.3	Party clearing	269
5.6.3.1	Terminology	269
5.6.3.2	Exception conditions	269

5.6.3.3	Dropping a party initiated by the user	270
5.6.3.4	Dropping a party initiated by the network	271
5.6.3.4.1	Clearing with a DROP PARTY message	272
5.6.3.5	Clear collision	273
5.6.4	Restart Procedure	273
5.6.5	Handling of error conditions	273
5.6.5.1	Protocol Discriminator Error	274
5.6.5.2	Message too short	274
5.6.5.3	Call reference and Endpoint Reference errors	274
5.6.5.3.1	Call reference procedural errors	274
5.6.5.3.2	Endpoint reference error	274
5.6.5.3.2.1	Invalid endpoint reference format	274
5.6.5.3.2.2	Endpoint reference procedural errors	274
5.6.5.4	Message type or message sequence errors	275
5.6.5.5	Message length errors	275
5.6.5.6	General Information Element errors	275
5.6.5.7	Mandatory information element error	275
5.6.5.7.1	Mandatory information element missing	275
5.6.5.7.2	Mandatory information element content error	276
5.6.5.8	Non-mandatory information element errors	276
5.6.5.8.1	Unrecognized information element	276
5.6.5.9	Signalling AAL reset	277
5.6.5.10	Signalling AAL failure	277
5.6.5.11	Status enquiry procedure	277
5.6.5.12	Receiving a STATUS message	278
5.7	List of Timers	280
5.7.1	Timers in the Network Side	280
5.7.2	Timers in the User Side	282
5.8	Address Registration	284
5.8.1	Overview	284
5.8.2	Capabilities	285
5.8.2.1	Initialization-time Exchange of Addressing Information	285
5.8.2.2	Restrictions on Network-Prefix/User-Part Combinations	285
5.8.2.3	Rejection of Unacceptable Values	285
5.8.2.4	Dynamic Addition/Deletion	286
5.8.2.5	De-registration on UNI "link down" Condition	286
5.8.3	General Description of Procedures	286
5.8.4	Management Information Base for Address Registration	287
5.8.4.1	Prefix Group (CR)	287
5.8.4.1.1	Network Prefix	287
5.8.4.1.2	Network Prefix Status	287
5.8.4.2	Address Group (CR)	287
5.8.4.2.1	ATM Address	287
5.8.4.2.2	ATM Address Status	287
5.8.5	Address Registration Procedures	288

5.8.5.1 Network-Side UME	288
5.8.5.2 User-Side UME	289
5.8.5.3 Retransmission of SetRequest Messages	290
5.8.6 MIB Definition	290
5.9 Signalling ATM Adaptation Layer (SAAL)	294
References	297
Annex A: Guidelines for Use of ATM Address Formats	300
Annex B: Compatibility Checking	303
Annex C: B-LLI Negotiation	304
C.1 General	304
C.2 B-LLI notification to the called user.	304
C.3 B-LLI negotiation between users	304
C.4 Alternate requested values	305
Annex D: Transit Network Selection	306
D.1 Selection not supported	306
D.2 Selection supported	306
Annex E: Cause Definitions	307
Annex F: ATM Adaptation Layer Parameters Negotiation	312
F.1 General	312
F.2 ATM adaptation layer parameter indication in the SETUP message	312
F.3 Maximum CPCS-SDU Size negotiation	313
F.4 MID range negotiation	314
F.5 Use of Forward and Backward Maximum CPCS-SDU Size by the AAL entity in the user plane	314
Appendix: A Quality of Service Guidelines	316
A.1 Introduction	316
A.1.1 Objective	316
A.1.2 Approach	316
A.1.3 Terminology	317
A.1.3.1 Cell Event	317
A.1.3.2 ATM Cell Transfer Outcome	317
A.2 QoS Reference Configuration	318
A.3 ATM Performance Parameters	320
A.3.1 Cell Error Parameters	320
A.3.1.1 Cell Error Ratio	320
A.3.1.2 Severely-Errored Cell Block Ratio	320
A.3.2 Cell Loss Ratio	321

A.3.3	Cell Misinsertion Rate	321
A.3.4	Cell Transfer Delay	321
A.3.4.1	Mean Cell Transfer Delay	321
A.3.4.2	Cell Delay Variation (CDV)	322
A.3.4.2.1	1-Point CDV	322
A.3.4.2.2	2-Point CDV	322
A.3.5	Quality of Service provided by the ATM Layer	322
A.4	QoS Classes	323
A.4.1	Specified QoS Classes	323
A.4.2	Unspecified QoS Class	324
A.5	Measurement Methods	325
A.5.1	Cell Error Parameters	325
A.5.1.1	Cell Error Ratio	325
A.5.1.2	Severely Errored Cell Block Ratio	325
A.5.2	Cell Loss Ratio	325
A.5.3	Cell Misinsertion Rate	326
A.5.4	Cell Transfer Delay	326
A.5.5	Measuring Cell Non Conformance Ratio	326
A.5.6	Measuring of Range of Cell Transfer Delay	327
A.6	Factors Affecting ATM QoS Performance Parameters	329
A.6.1	Sources of QoS Degradation	329
A.6.1.1	Propagation Delay	329
A.6.1.2	Media Error Statistics	329
A.6.1.3	Switch Architecture	329
A.6.1.4	Buffer Capacity	329
A.6.1.5	Traffic Load	329
A.6.1.6	Number of Nodes in Tandem	329
A.6.1.7	Resource Allocation	330
A.6.1.8	Failures	330
A.6.2	Impact of QoS Degradation on Performance Parameters	330
A.6.2.1	Cell Error Ratio and Severely Errored Cell Block Ratio	330
A.6.2.2	Cell Loss Ratio	330
A.6.2.3	Cell Misinsertion Rate	331
A.6.2.4	Cell Transfer Delay	331
A.6.2.4.1	Mean Cell Transfer Delay	331
A.6.2.4.2	Cell Delay Variation (CDV)	332
A.6.2.5	Degradation of QoS Parameters Summary	333
A.6.3	Principles of Allocation	333
Appendix B:	Conformance Examples in a Traffic Contract	334
B.1	Introduction	334
B.2	Example 1 Switched Multi-megabit Data Service (SMDS)[31]	335
B.3	Example 2a Frame Relay Service (FRS)[32]	336
B.4	Example 2b Frame Relay Service (FRS)	339

B.5 Example 3 Constant Bit Rate Services	340
B.6 Example 4 LAN Interconnection	341
Appendix C: Point-to-Multipoint Signalling Procedures Using Separate State Machines (Informative)	342
C.1 Introduction	342
C.2 Description of the Separate State Machines	342
C.2.1 Control Model	342
C.2.2 Party States and Link States	344
C.2.3 Primitives between the Multi-Party Control and the Link Control	344
C.2.4 Primitives between Point-to-Multipoint Control and Coordination Function	344
C.3. Information Flows for Point-to-Multipoint Communication	345
C.3.1 Functional Blocks used for the Description of Information Flows	345
C.3.2 Information Flows for the Successful Adding of a Party to an already Existing Call	346
C.3.2.1 Overall Description of Information Flows	346
C.3.2.2 Primitives between Point-toMultipoint Control and Link Control and between Coordination Function and Point-toMultipoint Control	347
C.3.2.3 Functional Entity Actions (FEAs)	348
C.3.3 Dropping of a Party from an Existing Point-to-Multipoint Call by the Root.	354
C.3.3.1 Overall Description of Information Flows	354
C.3.3.2 Primitives between Point-to-Multipoint Control and Link Control .	355
C.3.3.3 Functional Entity Actions (FEAs)	355
Appendix D: Example Signalling Codings	359
D.1 ATM Adaptation Layer Parameters	359
D.1.1 Example of information element coding for AAL1	359
D.1.2 Example of information element coding for AAL5	361
D.2 Broadband Bearer Capability	362
D.2.1 Example of information element coding for variable bit rate, connection oriented service with no timing requirements	362
D.3 Broadband Low Layer Information	363
D.3.1 Example of information element coding for multiprotocol interconnect using the LLC encapsulation	363
D.3.2 Example of information element coding for transport of IP datagrams using the "Null encapsulation" over AAL5	364
D.3.3 Example of information element coding for transport of bridged frames using the "Null encapsulation" over AAL5	365
Appendix E: Differences with ITU-T draft Recommendation Q.2931	363

Appendix F: Guidelines on the use of Bearer Class, Traffic Parameters and QoS	386
F.1 Bearer Class	386
F.1.1 BCOB-A	386
F.1.2 BCOB-C	386
F.1.3 BCOB-X	386
F.2 Allowed Combination of Bearer Capabilities, Traffic Parameters, and QoS.....	386
Appendix G: OAM Cell Error Detection Code Field	388
Appendix H: Glossary	389

List of Figures

Figure 1-1	Implementations of the ATM UNI	3
Figure 1-2	ATM Bearer Service Attributes	7
Figure 1-3	User-Network Interfaces Configuration	8
Figure 1-4	B-ISDN Protocol Reference Model	9
Figure 2-1	Physical Layer Functions (U-plane)	13
Figure 2-2	SONET STS-3c at the UNI	17
Figure 2-3	SONET Overhead Bytes at the UNI	18
Figure 2-4	Physical Layer Management at the UNI	19
Figure 2-5a	SONET Physical Layer OAM flow	20
Figure 2-5b	Example of OAM flow at the UNI	21
Figure 2-6	Physical Layer Functions	23
Figure 2-7	DS3 PLCP Frame (125 us)	24
Figure 2-8	Cycle/Stuff Counter Definition	26
Figure 2-9	PLCP Path Status (G1) Definition	26
Figure 2-10	POI Code Definition	27
Figure 2-11	Physical Layer Functions (U-plane)	29
Figure 2-12	Local Fiber Link	30
Figure 2-13	ATM Access Link Control Code Summary	31
Figure 2-14	HEC Verification Flow	33
Figure 2-15	Physical Layer Functions (U-plane)	34
Figure 2-16	Chromatic Dispersion Requirements	36
Figure 2-17	AOI Optical Transmit Parameters	37
Figure 2-18	MMF Eye Diagram for the Transmitter	38
Figure 2-19	All Optical Receive Parameters	39
Figure 2-20	Pin Assignment and Data Connector Detail	41
Figure 2-21	AOI Electrical Transmit Parameters	42
Figure 2-22	AOI Electrical Transmit Pulse Envelope	42
Figure 2-23	All Electrical Receive Parameters	43
Figure 2-24	Physical Layer Frame Format	44
Figure 2-25	Byte 6 Definition	44
Figure 2-26	Synchronization Symbols	44
Figure 2-27	HEC Verification Flow	46
Figure 3-1	ATM Service Access Point (SAP) Primitives	50
Figure 3-2	ATM-SAP Parameters	51
Figure 3-3	PHY-SAP Services Required by the ATM Layer	52
Figure 3-4	ATM Cell Structure at the UNI	53
Figure 3-5	ATM Field Encoding Convention	53
Figure 3-6	Functions supported at the UNI (U-plane)	55
Figure 3-7	Pre-Defined Header Field Values	57
Figure 3-8	Default Header Field Value	58
Figure 3-9	Payload Type Indicator Encoding	59

Figure 3-10	ATM Layer Management Functions at the UNI	61
Figure 3-11	ATM Layer OAM flows at the UNI	62
Figure 3-12a	Common OAM Cell Format	64
Figure 3-12b	OAM Cell Fault Management-Specific Fields	65
Figure 3-13	Loopback Function	68
Figure 3-14	Procedures Used to Set Values of Traffic Contract Parameters	75
Figure 3-15	Equivalent versions of the Generic Cell Rate Algorithm	79
Figure 3-16	PCR Reference Model	81
Figure 3-17	Ideal Cell Arrival at the Public UNI (t = 0.5d)	84
Figure 3-18	Possible Cell Arrival at the Public UNI (t = 1.5d)	84
Figure 3-19	Possible Cell Arrival at the Public UNI (t = 3.5d)	84
Figure 3-20	Possible Cell Arrival at the Public UNI (t = 7d)	84
Figure 3-21	SCR and Burst Tolerance Reference Model	85
Figure 3-22	Mapping Cell Loss Ratios for VCC and VPC	93
Figure 3-23	Location of the UPC Functions	98
Figure 4-1	Definition and Context of ILMI	106
Figure 4-2	Examples of Equipment Implementing the ATM UNI ILMI	109
Figure 4-3	ILMI ATM UNI MIB Tree Structure	111
Figure 5-1a	DCC ATM Format	160
Figure 5-1b	ICD ATM Format	160
Figure 5-1c	E.164 ATM Format	160
Figure 5-2	CALL PROCEEDING Message Contents	168
Figure 5-3	CONNECT Message Contents	170
Figure 5-4	CONNECT ACKNOWLEDGE Message Contents	171
Figure 5-5	RELEASE message content	171
Figure 5-6	RELEASE COMPLETE message content	172
Figure 5-7	SETUP message content	174
Figure 5-8	STATUS message content	175
Figure 5-9	STATUS ENQUIRY message content	176
Figure 5-10	RESTART message content	177
Figure 5-11	RESTART ACKNOWLEDGE message content	178
Figure 5-12	ADD PARTY message content	179
Figure 5-13	ADD PARTY ACKNOWLEDGE message content	181
Figure 5-14	ADD PARTY REJECT message content	181
Figure 5-15	DROP PARTY message content	182
Figure 5-16	DROP PARTY ACKNOWLEDGE message content	182
Figure 5-17	General Message Organization Example	183
Figure 5-18	Protocol Discriminator	184
Figure 5-19	Call Reference Information Element	186
Figure 5-20a	Encoding for Global Call Reference	187
Figure 5-20b	Encoding of the Dummy Call Reference	187
Figure 5-21	Message Type	187
Figure 5-22	Message Length	189

Figure 5-23	General Information Element Format	193
Figure 5-24	ATM Adaptation Layer Parameters Information Element (For all AAL Types)	196
Figure 5-25	ATM Adaptation Layer Parameters Information Element (Octet Groups 6-12 for AAL Type 1)	197
Figure 5-26	ATM Adaptation Layer Parameters Information Element (Octet Groups 6-10 for AAL Type 3/4)	198
Figure 5-27	ATM Adaptation Layer Parameters Information Element (Octet Groups 6-9 for AAL Type 5)	199
Figure 5-28	ATM Adaptation Layer Parameters Information Element (Octet Group 6 for User Defined AAL)	199
Figure 5-29	ATM Traffic Descriptor Information Element	205
Figure 5-30	Broadband Bearer Capability Information Element	209
Figure 5-31	Broadband High Layer Information Information Element	211
Figure 5-32	Broadband Low Layer Information Information Element	214
Figure 5-33	Call State Information Element	218
Figure 5-34	Called Party Number Information Element	219
Figure 5-35	Called Party Subaddress Information Element	221
Figure 5-36	Calling Party Number Information Element	222
Figure 5-37	Calling Party Subaddress Information Element	224
Figure 5-38	Cause Information Element	226
Figure 5-39	Connection Identifier Information Element	231
Figure 5-40	Quality of Service parameter Information Element	233
Figure 5-41	Broadband Repeat Indicator Information Element	235
Figure 5-42	Restart Indicator Information Element	236
Figure 5-43	Broadband Sending Complete Information Element	237
Figure 5-44	Transit Network Selection Information Element	238
Figure 5-45	Endpoint Reference Information Element	239
Figure 5-46	Endpoint State Information Element	240
Figure 5-47	SAAL Structure	296
Figure A-1	ATM QoS Reference Configuration	319
Figure A-2	Estimation of 2-point CDV from 1-point CDV for Connections providing CBR service	328
Figure A-3	Degradation of QoS Parameters	333
Figure B-1	Example 1	336
Figure B-2	Example 2a	338
Figure B-3	Example 2b	340
Figure B-4	Example 3	341
Figure C-1	Control Model with Separated State Machines	342
Figure C-2	State Machines of a Network involved in a Point-to-Multipoint Call	343
Figure C-3	Functional Blocks of a Point-to-Multipoint Call	346
Figure C-4	Information Flows for Successful Adding of a New Party	347
Figure C-5	Information Flows for a Local Acknowledgement of DROP PARTY	354

List of Tables

Table 5-1	Reference Configurations	153
Table 5-2	Messages for ATM Call and Connection Control	168
Table 5-3	Messages Used with the Global Call Reference	176
Table 5-4	Messages Used with ATM Point-to-multipoint call and connection control	178
Table 5-5	Information Element Identifier Coding (Codeset 0)	192
Table 5-6	General Information Element Format	193
Table 5-7	Allowable Combinations of Traffic Parameters in a Given Direction	208
Table 5-8	Combination of Traffic Parameters for Best Effort	208
Table 5-9	Timers in the network side	280
Table 5-10	Timers in the user side	282
Table C-1	Primitives Used between Link Control and Point-to-Multipoint Control	344
Table F-1	Allowable Combinations of Traffic Related Parameters in the SETUP message	387